

5、To distinguish and dispose the malfunction and abnormal

Phenomenon Cause	Disposal					
	Can not settle gas cartridge	No gas	Gas leakage	Flameout frequently	Flameout frequently	Flame out during using
Control knob do not turn to "OFF"	●					Turning the control knob to the "OFF" and setting the gas cartridge over again.
Open the pressure safety device		●			●	Please refer to the instruction of pressure safety device
Malfunction of the control knob		●	●	●	●	Sending it to repair
The inner pipe blocked		●	●	●	●	Sending it to repair
The settlement of gas cartridge incorrect	●	●			●	Match the hole of gas cartridge with the protuberance
The burner blocked			●	●	●	To clean it with metal brush
Electronic lighter inflected or rust					●	To clean the dirt
No gas		●	●	●	●	Renewed the gas cartridge with gas
Do not pull out the assistant Ignited Ring					●	Pulling out the assistant Ignited Ring

Daily check and maintenance:

- Please make the heater and gas cartridge separated when maintenance.
- Please don't break down and reassemble the heater as your will.
- Please maintain the heater after it cool down.

Have not use it for a long time:

- Please make sure the heater do not mildew or rust, keep it dry and clean.
- Put the heater into case after it cool down, keep it in the dry place.
- Keep the heater and gas cartridge separately.

6、Guarantee items

- Guarantee for one year from the date of purchase (against the purchase invoice and guarantee card).
- User use the heater under instruction correctly, when it happen accident in case, please contact with the franchiser.
- No guarantee in the following items:
 - Do not operate according to the instruction and notice, when in using, it cause the accident or mangle;
 - There is no record or altered the purchase date, user name and franchiser name on the guarantee card.
 - The invoice and guarantee card do not sign with the franchiser seal.

Heater guarantee card

Name:
Address:
Invoice No.:
Purchase Date:
Franchiser Name and address (seal with validity)
Tel No.:

Heater guarantee card return receipt

Name:
Address:
Invoice No.:
Purchase Date:
Franchiser Name and address (seal with validity)
Tel No.:

Baihui

INSTRUCTIONS OF THE OUTDOOR HEATER




BDN - 100

Thank you for your purchase our product, for your correct and safe to use this product, and keep it in good condition for a long time. Please operate it according to the instruction carefully.

1、The usage scope of heater.

- For camping using.
- For climbing mountain using.
- For fishing using.
- For various outdoor activities using.

2、Parts of Heater structure.



- | | |
|-----------------|------------------------|
| ① Handle | ⑥ Control knob plague |
| ② Panel | ⑦ Control knob |
| ③ Wiry frame | ⑧ Gas cartridge button |
| ④ Potery slate | ⑨ Orientation |
| ⑤ Gas can cover | ⑩ Pulling Ring |

3、Operation process.

① Put your finger into the bottle cover hole and open it.	② Make sure the control knob on the "OFF" and the pole knob on the "RELEASE".
③ Please use the appointed gas and settle it as the figure.	④ Press the pole knob to the "LOCK", turning the control knob anti-clockwise, when you hear the "KARK", you can ignite it.
⑤ Pulling out the assistant ignited Ring.	⑥ Turning the control knob anti-clockwise to ignite, and reposition the Ring.
⑦ Turning the control knob clockwise to "MIN" and anti-clockwise to "MAX".	⑧ Turning the control knob to the "OFF" to cut off the gas.
⑨ Turning the control knob clockwise to "OFF", and put the pole knob to the "RELEASE", and take off the bottle.	⑩ After you take off the bottle, there will be some lack gas in the pipe, please ignite it again, after that, you can turn off the control knob.

4、Pay attention to the following items while in using.

① Don't use the heater to dry clothing or flammable article, in that case, it may cause accident, such as, fire.	② When you are using the heater, do not cover anything on the heater, otherwise, it will cause accident or fire.
③ During the using or after used of the heater, do not touch the hot parts:panel, wiry frame, potery slate, until the heat cool down.	④ Don't use the heater to cook food, lest it cause some abnormal phenomenon.
⑤ Don't roast food on the heater, lest should make the oil or waste on the heat part, if so, it will cause the heater out of work.	⑥ Please don't use the heater in the unventilated room, because to use the heater under such situation, it will cause the smoke over normal level, it will make people feel dizzy.
⑦ After used up the gas in the can. Do not throw the used gas can into the fire or put it near the fire lest it explode. Be sure to make a hole with nail or drill in the used gas can before you throw it away.	⑧ Container groove must be fitted as the above figure!

Attention:

- Please finish the ignited process within two second. Do not hold the time more than three second, lest the leakage of gas, if so, it will cause moment flame out of the heater.
- When the gas cartridge under the sun irradiation directly or high temperature condition, it will lead to the inner gas over pressure, this phenomenon due to the safety device of the heater it will make it fall to operate. So, please cool down the gas cartridge, after that restled it will be ok.
- If use the non-standard gas cartridge, some cartridge is too long or inferior of the gas quality (not pure butane gas), over pressure, as the above reasons, it will cause the heater out of use. Please replace non-standard gas cartridge into the standard gas cartridge.
- During using or just after used, take care of the heat part and handle it carefully.
- Put the heater out of reach of child.